
Installation In New Construction

Viewing the 5 minute online new installation video at www.damsill.com is HIGHLY recommended.

STEP 1—Measure and Cut

- Measure the rough opening width from jamb to jamb.
- Cut DamSill on the end that places the drainage ports furthest away from the jamb.
- Make the cut exactly the same width as the rough opening.



STEP 2—Caulk and Install

- Apply caulk to the corners of the rough opening.
- Apply caulk to the <u>back side of</u> the <u>front flange</u>.
- Install DamSill in rough opening and press in place against the moisture barrier. Mark





USE ONLY ONE OF FOLLOWING RECOMMENDED SEALANTS FOR INSTALLATION:- Dow Corning 795 (not 790)- DAP® ALEX PLUS® Acrylic Latex Caulk Plus Silicone- OSI Quad Pro Series- OSI Ployseamseal All-Purpose Adhesive Caulk



Mark the drainage ports on the moisture barrier in order to use nail flange later.

STEP 3—End Dam Installation

- Snap the back flange off of a scrap piece of DamSill to use as an end dam.
- Measure, score with a utility knife and snap the end dam to the proper length.
- Apply caulk to back side of the end dam. Press end dam in place and caulk.
- Caulk exposed center channel where it was cut.



Snap off back flange from a scrap piece of DamSill





Seal center channel at cut



Installation In New Construction (Continued From Other Side)

Installing Window


- Place window and secure with side and top nailing flange.
- Avoid marked areas when using bottom nailing flange.
- Tape top and sides.
- DO NOT TAPE BOTTOM NAILING FLANGE!





DamSill In Ganged Windows

- Install exactly as shown in single window installation.
- Caulk DamSill sections together to make length of window opening.
- Avoid joining DamSill sections in line with mullions.
- Seal joint with approved sealant.



The Two-Minute DamSill **Installation Video Can Be** Viewed Online at www.damsill.com

Call **Moisture Warranty Corporation** at 800-400-8679 for orders or information

USE ONLY ONE OF FOLLOWING RECOMMENDED SEALANTS FOR INSTALLATION:

- DAP[®] ALEX PLUS[®] Acrylic Latex Caulk Plus Silicone - Dow Corning 795 (not 790) - OSI Quad Pro Series

- OSI Ployseamseal All-Purpose Adhesive Caulk